How to Test a GFCI



GFCIs can be damaged by voltage surges by lightning, utility switching or simply from normal usage. If they are not working properly, they are not protecting you from shock or electrocution. Follow these easy steps to test your GFCIs every month:



1. Push the RESET button.



2. Plug in a nightlight or similar device.



3. The nightlight should be ON.



4. Press the TEST button.




5. The nightlight should turn OFF.



6. Push the RESET button again.



7. The nightlight should turn back ON.





Malfunctioning GFCIs <u>do not</u> provide shock protection. Have a licensed, qualified electrician check the GFCI and correct the problem if your GFCI is not working.